

aFe Control *Front Suspension Strut Brace* *19-22 Mazda 3*

Product Number: 450-502003-G

Install Time: 10 Min. (Front Strut Brace),



Full Kit Contents	Front & Rear Sway Bar Set	Qty.
00P-0P2619-G	Strut Brace, Mazda 3, Gray	1
00P-0P2618-N	Plate, Logo: Strut Bar, Orange	1
00P-0C1765-A	Nut: M4x0.7, nylon locking	2
00P-0C1766-A	Screw: M4x0.7x10, Pan Head Phillips, 18-8SS, Blk	2
00P-0C1770-A	Nut, M10 X 1.25 Flanged	4

Recommended Tools:

- Sockets: 7mm, 15mm
- Phillips Head Screwdriver
- Socket Wrench
- Torque Wrench

Installation:

1. Using the supplied 4mm hardware, install the logo plate onto the underside of the strut brace.
2. Using the 15mm socket, remove the 4 inner nuts securing the struts to the chassis. They will not be re-used.
3. Install the strut brace with the supplied Hardware and Torque to 55 Nm (40 ft-lb)

