



# Silver Bullet

Throttle Body Spacer

PN 46-35001

## Important!

Please verify the parts list and read all instruction steps before you begin installation.

Make: JEEP

Model	Year	Engine
Cherokee (XJ)	91-01	4.0L
Grand Cherokee (WJ)	91-04	4.0L
Wrangler (TJ, YJ)	91-06	4.0L

1. Loosen and remove air inlet tube from air cleaner assembly. Loosen and remove air inlet assembly from throttle body.
2. Remove the four 6mm bolts from the throttle body assembly.
3. **(Mechanical Throttle Linkage Only)** Unbolt the two/three linkage retaining bolts from the linkage bracket.
4. Install a gasket, the aFe Silver Bullet throttle body spacer (AIR IN engraving side faces the throttle body), and another gasket and throttle body onto intake manifold. Using the washers and longer bolts secure the throttle body to intake manifold. Tighten the bolts to 10 Nm (89 lb/in).
5. **(Mechanical Throttle Linkage Only)** Install the two or three one-inch spacers under the linkage plate and secure them down with the longer bolts supplied. Tighten the bolts to 10Nm (89 lb/in).
6. Reinstall the air inlet assembly on the throttle body. Reattach the air inlet to air cleaner assembly.



### Parts List

- 1 aFe Silver Bullet Spacer
- 2 Gaskets
- 4 6mm x 50mm bolts
- 3 6mm x 40mm bolts
- 7 6mm washers
- 3 6mm x 1" Spacer

**advanced FLOW engineering**

252 Granite Street, Corona, CA 92879

Support: 951-493-7100

www.aFePower.com

Created 6/16/2008 (Rev 05/16/2013)